

Lemon Fresh

Premium Hand Dish Wash

Product Number 4247

Description

A rich mixture of emulsifiers, natural degreasers, and wetting agents designed to remove kitchen soils from dishes, glasses, pots, pans, and utensils. Removes soils and holds it in suspension for streak-free rinsing. A carefully blended product to insure mildness on hands. Concentrated to allow longer use before changing of wash water. Pleasant lemon fragrance.

Directions

Scrape excess soils from kitchenware. Prepare a sink with a solution of warm to hot water and add detergent at a rate of 1-2 ounces per 10 gallons of water. Place kitchenware into sink and wash. Rinse with clear water. Sanitize with recommended sanitizer. Place dishes aside to air dry. Heavy soils may require use of more detergent and a longer soaking time.

Technical Data

Color	Clear, Amber	Phosphated	No
Scent	Lemon	Viscosity	Medium
	High, Stable	Density	8.7 pounds/gallon
	7.5-7.7	·	

DOT Shipping Name: Compound, Cleaning, Liquid



WARNING

HAZARDS: Causes serious eye irritation.

PRECAUTIONS: Wash hands thoroughly after handling. Wear eye protection.

RESPONSE/FIRST AID: Have product container or label with you when calling poison control center or physician. **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists, get medical advice/attention. **IF ON SKIN:** Wash with plenty of soap and water. Take off contaminated clothing and wash before re-use. If skin irritation occurs, get medical advice/attention. **IF SWALLOWED:** Rinse mouth with water. Call a poison control center or physician for advice.

STORAGE & DISPOSAL: No GHS phrases apply. Dispose of contents/container to trash after rinsing container. Check your local, regional, and national regulations.