

Slide

Conveyor Lubricant for Trays and Plastic Cases

Product Number 4804

Description

A top quality, soap-based conveyor lubricant with high chelating value, low cloud point, and high active solids content. An optimum blend of synthetic detergents and water conditioners to provide maximum lubricity. Effective at a rate of 1:140 and can be used in positive (pump) and negative (suction) systems. Cleans while it lubricates.

Directions

Apply to all types of conveying apparatus to clean and lubricate. Use in continuous application on bottling/canning lines. Dilute to 1:150 for these applications. Use as a daily cleaner/lubricant for shackle chain and trolley after production in poultry and meat processing operations. Apply sparingly at dilution of 1:40 to 1:80. Allow 10-30 minutes dwell time and rinse thoroughly.

Technical Data

Form	Liquid	Foam	High
Color	Clear, Amber	Phosphorus	None
Odor	Bland	Viscosity	Medium
pH (1%).....	8-8.5	Density	8.60 lbs/gallon

DOT Shipping Name: Compound, Cleaning, Liquid



WARNING

HAZARDS: Causes mild skin irritation. Causes eye irritation.

PRECAUTIONS: Wash hands thoroughly after handling.

RESPONSE/FIRST AID: Have the product container or label with you when calling poison control center or physician. **IF IN EYES:** Flush eyes with plenty of water for at least 15 minutes, occasionally lifting the upper and lower eyelids. If irritation develops, get medical aid. **IF SWALLOWED:** If victim is conscious and alert, give 2-4 cupfuls of milk or water. Get medical aid if irritation or symptoms occur. **IF ON SKIN (or hair):** Get medical aid if irritation develops or persists. Flush skin with plenty of soap and water. **IF INHALED:** No specific treatment is necessary since this material is not likely to be hazardous by inhalation.

STORAGE & DISPOSAL: No GHS phrases apply. Dispose of contents/container in accordance with all local, regional, national and international regulations.

Crystal Chemical Company, Inc.

P. O. Box 539 • Warrington, PA 18976 • (215) 491-8690